




inoteska

A-MUX 32P

DOCUMENTATION



CONTENTS

1. General description	2
2. Applications	3
3. A-MUX specifications	5
4. Connectors of E1 and Ethernet interface	7
5. Connectors of analog interfaces	8
6. Modules FXS, FXO, IDTMF, E&M, LB	10
7. Module X.21	12
8. Interface RS 485	16
9. Technical parameters	17
10. Installing configuration SW	18
11. Settings	19
12. Configuring the device	23

1. General description




Name:	A-MUX 32P
Type nomenclature:	ITX 482 90, ITX 482 90.1, ITX 482 90.2 ITX 482 91, ITX 482 91.1, ITX 482 91.2 ITX 412 18, ITX 432 01, ITX 432 02, ITX 432 03
Manufacturer:	INOTESKA, s.r.o., Podtureň - Roveň 221, 033 01 Liptovský Hrádok
Placement:	Supervised areas
Dimensions:	43.5 x 237 x 220 mm (h x w x d)
Operational conditions:	0° C to 40° C, 20% to 75% relative atmospheric humidity
Storage:	-10° C to 60° C, 20% to 75% relative atmospheric humidity

A-MUX 32P enables to merge max.:

- 32 analog interfaces FXS
- 16 analog interfaces E&M
- 16 analog interfaces IDTMF
- 16 analog interfaces DDI 3W
- 8 analog interfaces FXO
- 8 analog interfaces LB
- 2 interfaces X.21
- 2 interfaces RS 485


Basic parameters:

- *signalling ISDN DSS1*
- *E1 framed n x 64 kbps (n = 1 to 31 timeslots)*
- *E1 120 Ohm*
- *Ethernet 10/100 BT interface on multiplexer main card*
- *Interface V.24 for multiplexer configuration from connected PC*
- *Multiplexer synchronization from E1 G.703 or from synchronous interface*
- *Power supply DC 48 V*



3. A- MUX specifications

	X.21	UDI	RS 485	E1	Rack / Stand alone	Ethernet	MUX	Conference
ITX 482 90	-	-	-	√	Stand alone	√	√	-
ITX 482 90.1	√	-	-	√	Stand alone	√	√	-
ITX 482 90.2	-	√	-	√	Stand alone	√	√	-
ITX 482 91	-	-	-	√	Stand alone	√	√	√
ITX 482 91.1	√	-	-	√	Stand alone	√	√	√
ITX 482 91.2	-	√	-	√	Stand alone	√	√	√
ITX 412 18	-	-	-	√	Rack	√	√	-
ITX 432 01	√	-	-	√	Rack	√	√	-
ITX 432 02	-	√	-	√	Rack	√	√	-
ITX 432 03	-	-	√	√	Rack	√	√	-



MUX – enables to merge analog or data interfaces to E1
Conference - up to 4 subscribers

Signification of LED diodes on the front panel:

STAT A - H - signalizes the seizure status of analog interfaces


ERR - ON – E1 interface not connected – loss of signal

SIG - ON – signalling error – no datalink connection

Signification of LED diode on the back panel:

PWR ITX 482 90.x power supply

RACK 6U:



Device can be supplied in following rack versions and power supply according to the table below:

	ITZ 802 01	ITZ 802 03	ITZ 802 05	ITZ 802 07	ITZ 802 09	ITZ 802 10	ITP 222 01	ITP 222 02	ITP 222 04	ITP 222 05	ITP 222 06
ITX 422 29	√	√	-	√	√	√	√	√	-	-	√
ITX 422 43	√	√	-	√	√	√	√	√	√	-	√
ITX 422 18	-	-	√	√	√	√	-	-	-	√	√
ITX 432 01	-	-	√	√	√	√	-	-	-	√	√
ITX 432 02	-	-	√	√	√	√	-	-	-	√	√
ITX 432 03	-	-	√	√	√	√	-	-	-	√	√

* - ITZ 802 05 can be embedded to both power supply positions in the rack. This can be used for back up of rack power supply.


4. Connectors of E1 and Ethernet interface

E1 interface - connector RJ 45


- 1 – input pin to device
- 2 – input pin to device
- 3 –
- 4 – output pin from device
- 5 – output pin from device
- 6 –
- 7 –
- 8 –

- RX -
- RX+

- TX -
- TX+




Ethernet 10/100 BT



RJ 45

- | | |
|--------------------------|------|
| 1 – Transmit from device | Tx + |
| 2 – Transmit from device | Tx - |
| 3 – Receive to device | Rx+ |
| 4 – | |
| 5 – | |
| 6 – Receive to device | Rx- |
| 7 – | |
| 8 – | |

5. Connectors of analog interfaces



Connectors RJ 45		CONNECTOR RJ 45 for ITP 182 25 – IDTMF								MODULE
		1	2	3	4	5	6	7	8	
1	A	a11	b11	a12	a13	b13	b12	a14	b14	IDTMF
	B	a21	b21	a22	a23	b23	b22	a24	b24	IDTMF
2	A	a31	b31	a32	a33	b332	b32	a34	b34	IDTMF
	B	a41	b41	a42	a43	b43	b42	a44	b44	IDTMF
3	A	a51	b51	a52	a53	b53	b52	a54	b54	IDTMF
	B	a61	b61	a62	a63	b63	b62	a64	b642	IDTMF
4	A	a71	b71	a72	a73	b73	b72	a74	b74	IDTMF
	B	a81	b81	a82	a83	b83	b82	a84	b84	IDTMF
5	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	
6	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	

Note: a, b – input and output audio wires to/from device (2-wire)

Identification: a32 – a wire, 3rd module

Connectors RJ 45		CONNECTOR RJ 45 for ITP 182 21 – E&M								MODULE
		1	2	3	4	5	6	7	8	
1	A	A11	B11	AI11	A12	B12	BI11	AI12	BI12	E&M
	B	A21	B21	AI21	A22	B22	BI21	AI22	BI22	E&M
2	A	A31	B31	AI31	A32	B32	BI31	AI32	BI32	E&M
	B	A41	B41	AI41	A42	B42	BI41	AI42	BI42	E&M
3	A	A51	B51	AI51	A52	B52	BI51	AI52	BI52	E&M
	B	A61	B61	AI61	A62	B62	BI61	AI62	BI62	E&M
4	A	A71	B71	AI71	A72	B72	BI71	AI72	BI72	E&M
	B	A81	B81	AI81	A82	B82	BI81	AI82	BI82	E&M
5	A	E11	M11	E12	M12	E21	M21	E22	M22	
	B	E31	M31	E32	M32	E41	M41	E42	M42	
6	A	E51	M51	E52	M52	E61	M61	E62	M62	
	B	E71	M71	E72	M72	E81	M81	E82	M82	

A, B – input/output audio wires from/to ITX 482 90 (2-wire)

Connectors RJ 45		CONNECTOR RJ 45 for ITP 182 22 – FXS								MODULE
		1	2	3	4	5	6	7	8	
1	A	A11	B11	A12	A13	B13	B12	A14	B14	FXS
	B	A21	B21	A22	A23	B23	B22	A24	B24	FXS
2	A	A31	B31	A32	A33	B33	B32	A34	B34	FXS
	B	A41	B41	A42	A43	B43	B42	A44	B44	FXS
3	A	A51	B51	A52	A53	B53	B52	A54	B54	FXS
	B	A61	B61	A62	A63	B63	B62	A64	B64	FXS
4	A	A71	B71	A72	A73	B73	B72	A74	B74	FXS
	B	A81	B81	A82	A83	B83	B82	A84	B84	FXS
5	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	
6	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	

A, B – input/output audio wires from/to ITX 482 90 (2-wire)

Connectors RJ 45		CONNECTOR RJ 45 for ITP 182 24 – 3W								MODULE
		1	2	3	4	5	6	7	8	
1	A	A11	B11	C11	A13	B13	-	C12	-	3W
	B	A21	B21	C21	A23	B23	-	C22	-	3W
2	A	A31	B31	C31	A33	B33	-	C32	-	3W
	B	A41	B41	C41	A43	B43	-	C42	-	3W
3	A	A51	B51	C51	A53	B53	-	C52	-	3W
	B	A61	B61	C61	A63	B63	-	C62	-	3W
4	A	A71	B71	C71	A73	B73	-	C72	-	3W
	B	A81	B81	C81	A83	B83	-	C82	-	3W
5	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	
6	A	-	-	-	-	-	-	-	-	
	B	-	-	-	-	-	-	-	-	

A, B – input/output audio wires from/to ITX 482 90 (2-wire)

6. Modules FXS, FXO, IDTMF, E&M, LB

It is possible to embed max. 8 modules.


ITP 182 25 can be used only together with devices **ITZ 910 21**, **ITX 422 37**, **ITX 422 43**, two-wire is used for connection. Four-wire can not be used.

Note:

It is possible to determine the HW position for each module, if necessary.


Module jumpers:

ITP 182 20 Module IDTMF



1. Trunk	2-wire	4-wire
PR 102	2-3	1-2
PR 103	2-3	1-2
PR 104	1-2	not connected
PR 105	1-2	not connected
PR 202	2-3	1-2
PR 203	2-3	1-2
PR 203	1-2	not connected
PR 205	1-2	not connected

ITP 135 17 Power supply module




HW jumpers

PR1 1 - 2 for power supply voltage -48 V
2 - 3 for power supply voltage -60 V

WARNING:

If power supply voltage is higher than 48V, the jumper must be 2 - 3!

7. Module X.21



Module with dual X.21 DCE interface n x 64 kbps

n = 1, 2, 3, to 31 timeslots


Connector X.21 D15F

RA – Receive A
 RB – Receive B
 TA – Transmit A
 TB – Transmit B
 CA – Control A
 CB – Control B

IA – Indication A
 IB – Indication B
 SA – Signal Timing A
 SB – Signal Timing B

Interface DTE is determined by cable:
 ITK 522 07 X.21 DCE – extension cable
 ITK 522 19 X.21 DTE – cable reduction


Cable ITK 522 07 – extension cable for X.21 DCE



CANNON - D15 M	Signal	Pairing	Colour designation of the wires	Signal	Cannon - D15 F
1	-		-	-	1
2	TXA		White (Orange)	TXA	2
3	CSA		White (Green)	CSA	3
4	RXA		White (Blue)	RXA	4
5	RCA		White (Brown)	RCA	5
6	TCA		White (Gray)	TCA	6
7					7
8	-		-	-	8
9	TXB		Orange (White)	TXB	9
10	SCB		Green (White)	SCB	10
11	RXB		Blue (White)	RXB	11
12	RCB		Brown (White)	RCB	12
13	TCB		Gray (White)	TCB	13
14	-		-	-	-
15	-		-	-	-
cover	-	-	shield	-	cover

↕ Paired wires
 ↕ Supplied cables have standard length of 1m. Different lengths are available upon request.

Cable ITK 522 19 – reduction for X.21 DTE



CANNON D15 M	Signal	Pairing	Colour designation of the wires	Signal	Cannon D15 M
1	-		-	-	1
2	TXA		White (Orange)	TXA	4
3	CSA		White (Green)	CSA	5
4	RXA		White (Blue)	RXA	2
5	RCA		White (Brown)	RCA	3
6	TCA		White (Gray)	TCA	7
7	RTCA		White (Red)	RTCA	6
8	GND		Yellow	GND	8
9	TXB		Orange	TXB	11
10	SCB		Green	SCB	12
11	RXB		Blue	RXB	9
12	RCB		Brown	RCB	10
13	TCB		Gray	TCB	14
14	RTCB		Red	RTCB	13
15	-		-	-	-
cover	-		shield	-	cover

↕ - Paired wires

Supplied cables have standard length of 1m. Different lengths can be specified in the order.

Cable Termination

TI – Termination Impedance


	TI 150 Ω	TI > 6 kΩ	TI 150 Ω	TI > 6 kΩ		
PR 20	1-2	n.c.	PR 10	1-2	n.c.	R
PR 21	1-2	n.c.	PR 11	1-2	n.c.	I
PR 22	1-2	n.c.	PR 12	1-2	n.c.	S

R – Data Receive

S – Synchronisation Receive

I – Control signal

8. Interface RS 485



Module ITP 137 21 2xRS 485 enables to transmit through one channel asynchronous data with Baud Rate 110 to 19200 Bd.

1. channell A1, B1

2. channell A2, B2

A is +

B is -

GND is galvanically separated from device power supply.

9. Technical parameters

Interface E1 G.703:	connector RJ 45
	framed G.704 PCM 30, PCM 31
Signalling:	PRI DSS 1
Line code:	HDB 3
Impedance:	120 Ohm
Analog interface:	connectors RJ 45
Signalling:	FXS, E&M, FXO, LB, IDTMF
Impedance:	600 Ohm
Interface X.21:	connector 15 pin D15 F
Synchronization:	- from G.703 - internally timed
Power supply:	- DC 48 V
Max. input:	
Desktop version:	max. 10VA
Rack version:	as per rack building-up
Dimensions:	237 x 220 x 43.5 mm (h x w x d) – desktop version
	19", 6 U , 250 mm – rack version
Weight:	2 kg – desktop version
	5 kg – rack version (empty)

10. Installing configuration SW

Management software

Management SW and this documentation is supplied together with the device on the attached CD.


Installing:

1. Insert CD.
2. Run setupxx.exe. Program operates under Windows '2000 or higher.
3. Proceed according to the instructions.

Running management SW:


Run M8290Axx.exe

After running the management software a password prompt will be displayed. The default set password is **inoteska**. After typing the right password and pressing OK, the settings' window will appear.




11. Settings

Run M8290Axx.exe




COMMUNICATION

Speed button **Setting of communication** enables to set communication parameters.



1) Set **Access type** – COM, MODEM, TCP, UDP

UDP - SW will find all devices connected in the network



2) Choose the device and click **Connect** – if device is connected, there is **Connected** message displayed.

Access type UDP – conditions for use:

If device is connected in network:

- Device must be in the same local network as PC
- Network must transmit *broadcast*
- PC has to always have IP address assigned.

If device is connected locally to PC:

- Arbitrary IP address must be assigned to PC. (DHCP must be OFF and static address must be set, e.g. 192.168.1.2)
- PC must have transmit/receive of *broadcast* packets
- PC must have UDP port 3864 enabled

In case of error, please check:


- System power source
- Device address **0-0-0-0** – local connection (device address can be changed (**Communication – Remote control & IP/Ethernet setting**): first number from interval 0 - 239, other three numbers from interval 0-255)

- Manager address 251-1-1-1 (first number from interval 240 –254, other three numbers from interval 0-255)
- Password correctness
- Serial port connection – crossed cable for Ethernet interface
- Cable between A-MUX and PC
- Settings of serial port in the connected PC
- Baud Rate between A-MUX and PC – 115 200 Bd. In case communication is done via another Inoteska device, Baud Rate is set as for the device next to A-MUX.

Default settings

If necessary, the configuration can be returned to the factory default by loading the file '**default.dat**' file.

Connection via modem



Click **Connect** if all parameters for communication are set. The connection with modem is initialized.

Remote control & IP/Ethernet setting

DEVICE IDENTIFICATION - serial number and HW assemblies

Identifikacia


TYP	ITX48290	Firmware	S8290 v1.9	Assembled module/data/E1
SN	482900050002			analog modul 0: NONE
RD	D			analog modul 1: NONE
CON	1			analog modul 2: NONE
ETH	1			analog modul 3: NONE
ANA	32			analog modul 4: NONE
E1	1			analog modul 5: NONE
DATA	1			analog modul 6: NONE
				analog modul 7: NONE
				data modul 0: X21
				ethernet: PRESENTED
				E1: PRESENTED

Permit Interfaces

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
ANA	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
ETH	x																															
E1	x																															
DATA																																

Info/List


CHANGE OF DEVICE PASSWORD



12. Configuring the device

Before setting subscribers' numbers and service numbers, it is efficient to have clear and rational numbering plan prepared before.

Parameters



Type of module for each HW position is set in the table:

- Not set (position is not occupied)
- FXS subscriber
- FXO trunk
- E&M T trunk - continuous signalling
- E&M trunk – pulse signalling
- IDTMF trunk – IDTMF signalling, communication with ITX 482 43 a ITX 482 37
- OPX trunk – off-premise extension trunk, connected to ITZ 910 21
- Inductive Trunk – against ITX 482 43
- Trunk DID – 3-wire

Subscriber numbers

For setting the FXS subscriber called number and name, following window is displayed.

The screenshot shows a window titled "Subscriber Numbers" with a close button (X) in the top right corner. At the top, there are three fields: "Position" with a dropdown menu showing "1", "Called Number" with a text box containing "51", and "Name" with an empty text box. Below these fields is a table with four columns: "Position", "Called Number", "HW typ", and "Name". The table contains 18 rows. The first four rows have "Called Number" values of 51, 52, 53, and 54, all with "HW typ" of "FXS Subscriber". The next two rows have "HW typ" of "E&M T Trunk". The remaining rows (6-18) are empty. To the right of the table are "Edit" and "Remove" buttons. At the bottom right of the window are "OK" and "Cancel" buttons.

Position	Called Number	HW typ	Name
1	51	FXS Subscriber	
2	52	FXS Subscriber	
3	53	FXS Subscriber	
4	54	FXS Subscriber	
5		E&M T Trunk	
6			
7		E&M T Trunk	
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			

Digital Trunk settings

The screenshot shows a 'Parameters' dialog box with the following settings:

- HW Position: 33
- HW Type: Digital Trunk
- Name: (empty)
- Call retrieve group: 1
- Dialed number in day service mode: (empty)
- Dialed number in night service mode: (empty)
- Level of transmitted DTMF signals: mute
- Additional digit on seize / release: 0
- Voice level: 6 dB
- Level of 16KHz receiver: -18 dB
- Diagnostics signal: 0
- Prefix identifikacie: (empty)
- Number of received digits to connection tone/voice: 0
- Parameters HW: ILIM=18mA
- Charging pulse length: 100 [80-200ms]
- Charging pulse frequency: 16 kHz
- Charging pulse amplitude: -2 dB
- Time table: 1
- Class of Services: 1
- Outgoing Dial Restrictions Table: 1
- Outgoing Dial Permissions Table: 1
- Diagnostic parameters: (empty)
- Signalling parameters: (empty)
- Dial parameters: (empty)
- Parameter 1: (empty)
- DigiPn: (empty)
- Type of table-correction of incoming dial:
 - Dial adjustment
 - According to digit analys
- Table number: 1
- Voice announcement/Tone: (empty)

CRC 4 – In case incoming line uses CRC multiframe.

Identification – In case the PBX connected to E1 transmits only the extension number in the identification, the identification can be extended to customer's complete number. For example PBX transmits only extension number 111, A-Mux can add 02 555 4444 to it.

Type of Signalling –type of signalling used for E1.

- ISDN - ISDN DSS1/Q signalling
- K+MFC-R2

Configuration PRA – Used for ISDN PRA line configuration

- NT – device simulates network termination
- TE – device simulates ISDN exchange

Signalling timeslot – determines the position of signalling timeslot

Timeslot Seizure – A side seizes from channel 1 upwards, B side from channel 31 downwards (ISDN PRA only)

Dial transmission:

Consecutive dial – device does not wait for the end of dial, but transmits the dial simultaneously (at the time the customer dials the destination number)

Dial in SETUP – For DSS1 the complete dial is transmitted in the DSS1 signalling.

12.2 Call groups

Subscribers can be categorized according to their function or physical placement (office, workshop, ...).

Example:

1. group - headquarters (2001, 2002, 2003)
2. group - workshops (2004, 2005 , 2006, 2007)
3. group - secretariat (2008, 2009, 2010)
4. group – fireroom, reception (2011, 2012)

Call Groups

Group type
 Cyclic

Free HW positions

HW position	Called number	Name
1	51	
2	52	
3	53	
4	54	

Add

Occupied HW positions

HW position	Called number	Name
1	51	
2	52	

Remove

Maximum number of members in the group is 32! Number of members in the group 2

Group 1 / Group 2 / Group 3 / Group 4 / Group 5 / Group 6 / Group 7 / Group 8 / Group 9

OK Cancel

Group type Cyclic – if group type is not set as cyclic, when calling to group , free subscriber is being found from the first one in the group. If group type is cyclic, system is searching from first subscriber in the group when first calling, from second subscriber when second calling, ... – cyclic round.

Choose the subscriber in **"Free HW positions"** – mark it with cursor and click on **"Add"**. In case of change, choose the subscriber in **„Occupied HW positions“** and click on **"Remove"**. Then subscriber will be moved to **"Free HW positions"**.

Group numbers

For set groups, set also numbers for :

- normal calls
- serial calls
- general calls

	Normal Calls	Serial Calls	General Calls
Calling number of group 1.	61	62	63
Calling number of group 2.	64	65	66
Calling number of group 3.			
Calling number of group 4.			
Calling number of group 5.			
Calling number of group 6.			
Calling number of group 7.			
Calling number of group 8.			
Calling number of group 9.			
Calling number of group 10.			
Calling number of group 11.			
Calling number of group 12.			
Calling number of group 13.			
Calling number of group 14.			
Calling number of group 15.			
Calling number of group 16.			

OK Cancel

12.3 Outgoing Dial Permissions and Restrictions Table


System enables the restriction of outgoing calls. That means it is possible to set dial permissions and restrictions for each subscriber. It can be restricted to call national numbers, but can be permitted to call certain national numbers (employees can not use the telephone for private purposes, but in case of emergency they can call the supervisor). Permission has higher priority than restriction.

The screenshot shows a dialog box titled "Outgoing Dial Permissions Table". It features a text input field for "Phone number" at the top. Below it is a larger list area, also labeled "Phone number", which is currently empty. To the right of this list are four buttons: "Add", "Edit", "Del", and "Reset". At the bottom right of the list area, there is a note: "Note: ? - arbitrary digit" and "Number of items: 0". The dialog box has a standard Windows-style title bar with a close button (X) and a tabbed interface at the bottom showing "Tab 1" through "Tab 10". At the very bottom, there are "OK" and "Cancel" buttons.

The screenshot shows a dialog box titled "Outgoing Dial Restrictions Table". It features a text input field for "Phone number" at the top. Below it is a larger list area, also labeled "Phone number", which is currently empty. To the right of this list are four buttons: "Add", "Edit", "Del", and "Reset". At the bottom right of the list area, there is a note: "Note: ? - arbitrary digit" and "Number of items: 0". The dialog box has a standard Windows-style title bar with a close button (X) and a tabbed interface at the bottom showing "Tab 1" through "Tab 10". At the very bottom, there are "OK" and "Cancel" buttons.

12.4 Trunk Groups

The trunks are formed to the groups. Each group has its permissions. Subscribers have permitted/restricted access to the trunks with defined parameters.




The groups can be formed only of the same type trunks.

It is possible to make up to 16 trunk groups.

When setting, all trunks are displayed in "**Free HW positions**". By clicking on the button on the right side, trunks are added to the groups.


Specific characteristics can be set for individual trunks.(Type 1)



12.5 Dial adjustment


Table number 1 to 16

It is possible to suppress the defined number of digits (and if necessary to substitute them with another numbers' combination) for outgoing as well as incoming call.




12.6 Dial adjustment according to dial analysis

Digits received by system are analyzed. When incoming/outgoing dial analysis is activated, system will suppress or substitute the coming digit.



12.7 Voice announcement parameters

It is possible to connect voice announcement to the trunk groups.
 Editing the voice announcement – System parameters – 2. Page - "Voice announcement parameters".



12.8 Trunk group calling numbers

Trunk Group	Calling number	1	2	3	4	5	6	7	8	9	10	11	12
1	1	0	0	0	x				0				
2	2	0	0	0	x				0				
3	3	0	0	0	x				0				


Example:

4 trunk groups are defined – 2 FXO trunks and 2 E&M trunks. Access to the each trunks is defined in Class of services. By setting the codes 9, 10, 11, 12 we will ensure that we will access certain trunk by calling its code.


E&M trunks - in "**Parameters**" buttons for setting diagnostic and signalling parameters are displayed.

According to the characteristics of device, to which A-MUX will be connected, activate following options:

- Seize acknowledge
- Pulse seize acknowledge
- Release acknowledge
- Pulse backward release
- Continuous backward release
- Wait for dialtone
- Evaluate busy tone as release
- Send/detect connect



12.9 Day/night service mode



Incoming call in day/night service mode is routed to the subscriber or group. (Example: 2003 – day service mode, 2004 – night service mode).

12.10 Class of Services

Class of Services [X]

Access to	Allowed Overflow of	Special Access to
<input checked="" type="checkbox"/> Trunk Group 1	<input type="checkbox"/> Trunk Group 1	<input type="radio"/> Trunk Group 1
<input checked="" type="checkbox"/> Trunk Group 2	<input type="checkbox"/> Trunk Group 2	<input type="radio"/> Trunk Group 2
<input checked="" type="checkbox"/> Trunk Group 3	<input type="checkbox"/> Trunk Group 3	<input type="radio"/> Trunk Group 3
<input type="checkbox"/> Trunk Group 4	<input type="checkbox"/> Trunk Group 4	<input type="radio"/> Trunk Group 4
<input type="checkbox"/> Trunk Group 5	<input type="checkbox"/> Trunk Group 5	<input type="radio"/> Trunk Group 5
<input type="checkbox"/> Trunk Group 6	<input type="checkbox"/> Trunk Group 6	<input type="radio"/> Trunk Group 6
<input type="checkbox"/> Trunk Group 7	<input type="checkbox"/> Trunk Group 7	<input type="radio"/> Trunk Group 7
<input type="checkbox"/> Trunk Group 8	<input type="checkbox"/> Trunk Group 8	<input type="radio"/> Trunk Group 8
<input type="checkbox"/> Trunk Group 9	<input type="checkbox"/> Trunk Group 9	
<input type="checkbox"/> Trunk Group 10	<input type="checkbox"/> Trunk Group 10	
<input type="checkbox"/> Trunk Group 11	<input type="checkbox"/> Trunk Group 11	
<input type="checkbox"/> Trunk Group 12	<input type="checkbox"/> Trunk Group 12	
<input type="checkbox"/> Trunk Group 13	<input type="checkbox"/> Trunk Group 13	
<input type="checkbox"/> Trunk Group 14	<input type="checkbox"/> Trunk Group 14	
<input type="checkbox"/> Trunk Group 15	<input type="checkbox"/> Trunk Group 15	
<input type="checkbox"/> Trunk Group 16	<input type="checkbox"/> Trunk Group 16	

1.page / 2.page

Class 1 / Class 2 / Class 3 / Class 4 / Class 5 / Class 6 / Class 7 / Class 8 / Class 9 / []

[OK] [Cancel] [Reset]

Class of Services [X]

- Contact Supervision
- Hotline, Passive subscriber extension
- Direct access to special trunk group on off-hook
- Activate call forwarding
- Interception protection
- Enable blocking of calls
- Enable service and diagnostics functions
- Enable trunk direct access
- Disable trunk seize if another trunk is on hold
- Disable callback after holding a trunk and consecutive on-hook
- Disable callback after holding a subscriber and consecutive on-hook
- Disable transfer of outgoing call to PSTN
- Non-working numbers route to special trunk group

1.page / 2.page

Class 1 / Class 2 / Class 3 / Class 4 / Class 5 / Class 6 / Class 7 / Class 8 / Class 9 / []

[OK] [Cancel]

- System enables to categorize all subscribers according to their work position to the 16 groups. That means they have access to all trunks. If one is busy, they have access also to another. Production workers can only have access to the one trunk to PSTN, if this is busy, they get busy tone. Reception employee can only dial through E&M trunk. This group doesn't have access to FXO trunk.
- Active call forwarding means that if all one trunk is busy and an overflow for subscriber number (in Class of services) is permitted, subscriber will be connected to another trunk group.

Class of services is assigned in „Parameters“ window.
Click on OK to save the settings.


12.11 Service numbers

Service numbers are set according to the numbering plan.


Service Option	Checkbox
Callback	<input type="checkbox"/>
Disable callback	<input type="checkbox"/>
Forwarding - follow me	<input type="checkbox"/>
Forwarding - busy	<input type="checkbox"/>
Forwarding - no answer	<input type="checkbox"/>
Forwarding - no answer or busy	<input type="checkbox"/>
Remote forwarding	<input type="checkbox"/>
Disable forwarding	<input type="checkbox"/>
Call retrieve in a group	<input type="checkbox"/>
Direct call retrieve	<input type="checkbox"/>
Direct access to trunk	<input type="checkbox"/>
Call parking	<input type="checkbox"/>
Restoring a parked call - local	<input type="checkbox"/>
Restoring a parked call - remote	<input type="checkbox"/>
Block incoming calls	<input type="checkbox"/>
Unblock incoming calls	<input type="checkbox"/>

1.strana 2.strana

OK Cancel



13. Data interfaces



14. Parameters


Optional:

Dial parameters

„Disable reception of dial during a call“ is set by default.

Speed dial

System enables to save up to 99 most frequently called numbers.



Example: Three of top managers often call to their partner in Czech Republic. To make it more simple his direct number is set and managers only remember a code of customer (01 to 99).

Note:

When setting a full number it is necessary to set also a code to the trunks to PSTN (9 and 10).

15. Service settings

15.1 System parameters

System Parameters [X]

Time supervision of services [s]

Time to switch to day service mode (hr:min)

Time to switch to night service mode (hr:min)

Modem baud rate

Max. number of voice announcements

Max. number of 3 party conference calls

Max. number of 4 party conference calls

Fax (modem) number

Units per pulse

Mode type in Saturday

Mode type in Sunday

Remote access number 1

Remote access number 2

Music on hold:

- external
- internal

Detailed Call Log Parameters

- Log calls to PSTN
- Log internal calls
- Log incoming calls
- Log outgoing calls
- Log calls only with charging pulses > 0
- bufer NVRAM
- bufer 1MB v Subore
- bez bufra vypis na CON
- bufer NVRAM vypis na ETH TCP/IP
- bufer NVRAM vypis na ETH UDP/IP
- bufer NVRAM vypis cez dohlad

15.2 Time Table

System allows the setting of 16 optional time tables. Table 1 is default and recommended.

The screenshot shows a configuration window titled "Time Table" with a close button (X) in the top right corner. The window contains a list of parameters with corresponding input fields and units:

- DTMF tone length: 100 [ms]
- DTMF interdigit pause: 100 [ms]
- Seize length: 100 [ms]
- Pulse length: 60 [ms]
- Pause length: 40 [ms]
- Seize acknowledge length: 100 [ms]
- Interdigit pause length: 800 [ms]
- Connect length: 100 [ms]
- Release length: 600 [ms]
- Backward release length: 600 [ms]
- Length of pulse for pulse release: 50 [ms]
- Pulse release pause: 50 [ms]
- Seize acknowledge time: 100 [ms]

At the bottom of the window, there is a tabbed interface with tabs labeled "1.page", "2.page", "3.page", and "4.page". Below the tabs are "Load" and "Save" buttons, and at the very bottom, "OK" and "Cancel" buttons.

The screenshot shows a configuration window titled "Time Table" with a close button (X) in the top right corner. The window contains a list of parameters with corresponding input fields and units:

- Block time after release: 1000 [ms]
- Release acknowledge time: 100 [ms]
- Maximum seize length: 400 [ms]
- Seize acknowledge / Dial tone timeout: 6000 [ms]
- Maximum release length: 1400 [ms]
- Minimum release length: 450 [ms]
- Release complete timeout: 1400 [ms]
- Maximum time between 2 ringings: 7000 [ms]
- Minimum valid ringing time: 200 [ms]
- Blocking time after release for incoming PSTN calls: 7000 [ms]
- Minimum valid time of the evaluated tone: 150 [ms]
- Interval length for tone evaluation: 4 [s]
- Minimum number of tones per interval for evaluation of valid busy tone: 5

At the bottom of the window, there is a tabbed interface with tabs labeled "1.page", "2.page", "3.page", and "4.page". Below the tabs are "Load" and "Save" buttons, and at the very bottom, "OK" and "Cancel" buttons.

Time Table [X]

Length of suppressed flash tones	<input type="text" value="20"/>	[ms]
Pulse dial evaluation time	<input type="text" value="200"/>	[ms]
Charging pulse evaluation time	<input type="text" value="100"/>	[ms]
Time for TX of first digit after seize	<input type="text" value="1000"/>	[ms]
Length of disgnostics interval	<input type="text" value="30"/>	[s]
Number of bad diagnostics intervals before error generation	<input type="text" value="3"/>	
Tone length at diagnostics error	<input type="text" value="1"/>	[s]
Pause length at diagnostics error	<input type="text" value="2"/>	[s]
Pause length at dial transmission	<input type="text" value="500"/>	[ms]
Maximum flash time	<input type="text" value="800"/>	[ms]
First digit local dial timeout	<input type="text" value="20"/>	[s]
Local dial timeout	<input type="text" value="20"/>	[s]
First digit outgoing dial timeout	<input type="text" value="20"/>	[s]

1.page / 2.page / 3.page / 4.page /

Load Save

Tab 1 / Tab 2 / Tab 3 / Tab 4 / Tab 5 / Tab 6 / Tab 7 / Tab 8 / Tab 9 / Tab 10 / Tab 11 / [F1]

OK Cancel

Time Table [X]

Outgoing dial timeout	<input type="text" value="20"/>	[s]
Block time of reception of dial during a call	<input type="text" value="1"/>	[s]
Repeated notice - subscriber not answering	<input type="text" value="20"/>	[s]
Repeated notice - hold	<input type="text" value="20"/>	[s]
Repeated notice - parking	<input type="text" value="40"/>	[s]
Time for switching to lock out state	<input type="text" value="30"/>	[s]
Time for forwarding - subscriber not answering	<input type="text" value="20"/>	[s]
Maximal time for ringing	<input type="text" value="300"/>	[s]
Time for switching to call wait state	<input type="text" value="10"/>	[s]
Maximal call wait time	<input type="text" value="40"/>	[s]
Maximal callback time	<input type="text" value="20"/>	[s]
Serial ring time	<input type="text" value="15"/>	[s]

1.page / 2.page / 3.page / 4.page /


Load Save

Tab 1 / Tab 2 / Tab 3 / Tab 4 / Tab 5 / Tab 6 / Tab 7 / Tab 8 / Tab 9 / Tab 10 / Tab 11 / [F1]


OK Cancel

15.3 Tone Table

Following tables contain standardly used tones in the telecommunication networks. In case customers wants the own ones to be set, he'll change these table settings.



16. E1 Diagnostics



Loss of Signal LOS – Loss of signal on link level - E1 interface not connected

Alarm Indication Signal AIS – Transmitted signal is constant with data value Log1

Loss of Frame Alignment LFA – Indicates synchronisation error in 0th channel

Receive Remote Alarm RRA – Indicates remote device alarm

Frame Error Counter FEC – Indicates error rate > 10⁻³

Receive Timeslot 16 Loss of Signal TS16LOS – Receive timeslot 16 does not contain signalling

Datalink layer not active – Link layer error – ISDN DSS1 signalling only

Slip Detection Indicator SDI – Indicates positive slip if the device clock has higher frequency than the clock signal received, and negative slip if it has lower frequency